

Intermediate maintenance (C markets*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) as of 2012 model

| | Work instruction for | | |
|--|----------------------------------|---|----------|
| Vehicle Ident. No. | order no. | | |
| | | | |
| ☐ Intermediate maintenance | | | |
| at 30,000, 90,000, 150,000, 210,000 km/18,000, (Labour operation 03 14 00) | 54,000, 90,000, 126,000 mil | les etc. | |
| For descriptions of the individual maintenance tasks, | see PIWIS Information System | Workshop Manual | |
| Information: If the mileage for a regular service is not read | | • | |
| The term "checking" includes all necessary subsequent w | | ting, correcting and topping up, but does | |
| not include repairing, replacing and reconditioning parts o | r assemblies. | | √ |
| Electrics | | | + |
| Windscreen wiper/washer system, headlight cleaning sys | tem: check function | | |
| Horn: check function | | | \Box |
| Tyres: check tyre pressure (TPM) | | | |
| Diagnostic system: read out fault memory; reset maintena | ance interval | | |
| Inside the vehicle | | | |
| Particle filter: replace filter element | | | |
| Luggage compartment | | | |
| Check front lid lock and safety hook of the front lid to ensu | ure that they are secure and fun | nction properly | |
| Replace air intake pre-filter | | | |
| Windscreen wiper/washer system: check fluid level; check | k window cleaner and antifreeze | e, depending on time of year, only use | |
| windscreen cleaners approved by Porsche | | | |
| Outside the vehicle | | | |
| Mix fuel in fuel tank with additive (Keropur from Porsche; | Part No. 000 043 206 89)** | | |
| Check wiper blades | | | |
| All headlights: check adjustment | | | |
| Radiators and air intakes: visual inspection for exteri | or soiling and blockage | | |
| Under the vehicle | | | |
| Drain engine oil | | | |
| Tyres: check condition | | | |
| Brake lines: visual inspection for damage, routing and cor | rosion | | |
| Brake hoses: visual inspection for damage | | | |
| Brake system: visual inspection of brake pads and brake | discs for wear (without removin | g and fitting wheels) | |
| Drive shafts: visual inspection of the boots for leaks and of | | | |
| Engine compartment | | | |
| Change oil filter | | | |
| Fill in engine oil | | | |
| Coolant: check level and antifreeze | | | |
| PDCC: check fluid level | | | |

^{*} For country allocation, see overview of A, B and C markets ** Applies only for China



Intermediate maintenance (C markets*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) as of 2012 model

| Vehicle Ident. No | Work instruction for order no. | | |
|---|--|-----|--|
| | <u>-</u> | | |
| ☐ Additional maintenance for spark plugs (Labour operation 03 81 00) | | Ī✓ | |
| Replace spark plugs | every 30,000 km/18,000 mls or every 4 years | • | |
| ☐ Additional maintenance for drive belt | , | • | |
| (Labour operation 03 60 00) | | | |
| Check drive belt | at 60,000 km/36,000 mls or every 4 years | | |
| Check drive belt | at 150,000 km/90,000 mls or every 10 years | | |
| Check drive belt | at 240,000 km/144,000 mls or every 16 years | | |
| ☐ Additional maintenance for convertible top (Labour operation 03 70 00) | | | |
| Service and maintain convertible top | every 30,000 km/18,000 mls or every 2 years | | |
| ☐ Additional maintenance every 90,000 km/54,00 (Labour operation 03 83 00) Replace PDCC reservoir | 0 mls or every 6 years | | |
| Replace drive belt | | | |
| Controlled all-wheel drive: change oil | | | |
| ☐ Additional maintenance every 120,000 km/72,0 (Labour operation 03 85 00) | 00 mls or every 4 years | • | |
| Ancillary unit mounts and chassis: visual inspection of all r | ubber mountings and boots for damage | | |
| ☐ Additional maintenance every 180,000 km/108, (Labour operation 03 88 00) | 000 mls or every 12 years | | |
| Manual transmission: change oil | | | |
| All-wheel final drive: change oil | | | |
| PDK transmission: change transmission oil | | | |
| PDK transmission: change clutch fluid | | | |
| ☐ Every 2 years | | | |
| (Labour operation 03 51 00) | | 1 | |
| Change brake fluid (use only original Porsche brake fluid) Prepare condition report for long-life guarantee | | | |
| | | | |
| ☐ Every 4 years | | | |
| (Labour operation 03 52 00) Replace tyre sealant | | | |
| Tropiace tyre scalarit | | | |
| Signature (mechanic): | | | |
| Test drive: | | | |
| ParkAssist, cruise control, PSM switch, PASM switch, Spo | t brake (also actuation travel), engine, clutch, steering, trans rt switch, sports exhaust system, door mirror fold-in function | | |
| conditioning and instruments: check function Oils, fluids: visual inspection for leaks | | | |
| Oils, fiulus. Visual irispection for leaks | | | |
| | | | |
| Signature (final check): | | | |
| <u>-</u> | ' | l | |
| | | | |
| | Porsche Cent | tre | |