

# PORSCHE

## Maintenance (C markets\*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) as of 2012 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction for  
order no.

--

**Maintenance**

at 60,000, 120,000, 180,000, 240,000 km/36,000, 72,000, 108,000, 144,000 miles etc.  
(Labour operation 03 16 00 ..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual  
Information: If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.



<b>Electrics</b>	
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory; reset maintenance interval	
<b>Inside the vehicle</b>	
Particle filter: replace filter element	
Seat belts: check function and condition	
Door locks: check function	
<b>Luggage compartment</b>	
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly	
Replace air intake pre-filter	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche	
<b>Outside the vehicle</b>	
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)**	
Check wiper blades	
All headlights: check adjustment	
Radiators and air intakes: visual inspection for exterior soiling and blockage	
Brake system: visual inspection of brake pads and brake discs for wear	
Brake hoses: visual inspection for damage	
<b>Under the vehicle</b>	
Drain engine oil	
Underbody panels: visual inspection for completeness, secure installation and damage	
Tyres: check condition	
Visual inspection for leaks (oils and other fluids)	
Brake lines: visual inspection for damage, routing and corrosion	
Steering gear: visual inspection of the bellows for damage	
Tie rod joints: check the play and dust bellows	
Drive shafts: visual inspection of the boots for leaks and damage	
Axle joints: check the play and visually inspect the dust boots for damage	
Exhaust system: visual inspection for leaks and damage, check engine mountings	
<b>Engine compartment</b>	
Air cleaner: replace filter elements	
Change oil filter	
Fill in engine oil	
Fuel lines and connections: visual inspection	
Visual inspection for leaks (oils and other fluids)	
Coolant: check level and antifreeze	
PDCC: check fluid level	

\* For country allocation, see overview of A, B and C markets

\*\* Applies only for China

# PORSCHE

## Maintenance (C markets\*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) as of 2012 model

Vehicle Ident. No. \_\_\_\_\_

Work instruction for  
order no.

--

- Additional maintenance for spark plugs**  
(Labour operation 03 81 00 ..)

Replace spark plugs	every 30,000 km/18,000 mls or every 4 years	<input checked="" type="checkbox"/>
---------------------	---	-------------------------------------

- Additional maintenance for drive belt**  
(Labour operation 03 60 00 ..)

Check drive belt	at 60,000 km/36,000 mls or every 4 years	
Check drive belt	at 150,000 km/90,000 mls or every 10 years	
Check drive belt	at 240,000 km/144,000 mls or every 16 years	

- Additional maintenance for convertible top**  
(Labour operation 03 70 00 ..)

Service and maintain convertible top	every 30,000 km/18,000 mls or every 2 years	
--------------------------------------	---	--

- Additional maintenance every 90,000 km/54,000 mls or every 6 years**  
(Labour operation 03 83 00 ..)

Replace PDCC reservoir		
Replace drive belt		
Controlled all-wheel drive: change oil		

- Additional maintenance every 120,000 km/72,000 mls or every 4 years**  
(Labour operation 03 85 00 ..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage		
---	--	--

- Additional maintenance every 180,000 km/108,000 mls or every 12 years**  
(Labour operation 03 88 00 ..)

Manual transmission: change oil		
All-wheel final drive: change oil		
PDK transmission: change transmission oil		
PDK transmission: change clutch fluid		

- Every 2 years**  
(Labour operation 03 51 00 ..)

Change brake fluid (use only original Porsche brake fluid)		
Prepare condition report for long-life guarantee		

- Every 4 years**  
(Labour operation 03 52 00 ..)

Replace tyre sealant		
----------------------	--	--

Signature (mechanic): \_\_\_\_\_

**Test drive:**

Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, PASM switch, Sport switch, sports exhaust system, door mirror fold-in function, heating, air conditioning and instruments: check function		
Oils, fluids: visual inspection for leaks		

Signature (final check): \_\_\_\_\_

--

Porsche Centre