

# PORSCHE

## Intermediate maintenance (China) 911 GT2 (997) as of 2009 model

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Intermediate maintenance**

at 20,000, 60,000, 100,000, 140,000 km/12,000, 36,000, 60,000, 84,000 miles etc.  
(Labour operation 03 14 00 ..)

For a description of the various models, see Technical Manual

**Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10..... years.

The term 'checking' includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

	✓
Mix fuel in the tank with additive (Keropur from Porsche; Part No. 000 043 206 89) and check and if necessary affix additional Chinese sticker relating to fuel quality on the tank cap	
Diagnostic system: read out fault memory; reset maintenance interval	
Change engine oil and oil filter (please observe oil change service plan for the 911 GT2)	
Vehicle underbody and engine compartment: visual inspection for leaks (oils and fluids) and chafing damage (lines and hoses) Underbody panels: visual inspection for completeness, secure installation and damage	
Coolant hoses: check condition	
Radiators and air inlets: visual inspection for external contamination and blockage	
Coolant: check level and antifreeze	
Particle filter: replace filter element	
Brake hoses and lines: visual inspection for leaks, damage, routing and corrosion	
Drive shafts: visual inspection of the boots for leaks and damage	
Tyres: check condition and tyre pressure	
Check the door locks, lid locks and safety hooks of the front lid to ensure that they are secure and functioning properly	
Vehicle lighting: check operation All headlights: check adjustment Horn: check operation	
Windscreen wiper/washer system, headlight cleaning system: check fluid level and nozzle settings, check antifreeze in winter months; check wiper blades	
Electrical equipment, warning and indicator lights: check operation	
Battery: check functional state and fluid level	
Replace spark plugs: see Additional maintenance	

Continued overleaf

# PORSCHE

## Intermediate maintenance (China) 911 GT2 (997) as of 2009 model

Vehicle Ident. No. \_\_\_\_\_

Working instruction  
for order no.

--

**Additional maintenance for spark plugs**  
(Labour operation 03 81 00 ..)

Replace spark plugs 911 GT2	every 20,000 km/12,000 miles or every 2 years	<input checked="" type="checkbox"/>
-----------------------------	---	-------------------------------------

**Additional maintenance every 80,000 km/48,000 miles or every 6 years**  
(Labour operation 03 82 00 ..)

Replace drive belt		
Replace fuel filter		

**Additional maintenance every 160,000 km/96,000 miles or every 12 years**  
(Labour operation 03 86 00 ..)

Manual transmission: change oil		
---------------------------------	--	--

**Every 2 years**

File condition report for long-life guarantee		
Change brake fluid		

**Every 4 years**

Replace tyre sealant		
----------------------	--	--

**After 4 years, then every 2 years**

Check tyre pressure monitoring system battery		
---	--	--

**After 4, 8, 10 years, then every 2 years**

Ancillary unit mounts and suspension: visual inspection of all rubber mountings and boots for damage		
--	--	--

Signature (fitter): \_\_\_\_\_

**Test drive:**

Remote control, front seats, footbrake and handbrake (also actuation travel), engine, clutch, steering, transmission, cruise control, TC switch, PASM switch, sports switch, heating, air conditioning and instruments: check operation		
Oils, fluids: visual inspection for leaks		

Signature (final check): \_\_\_\_\_