

Maintenance (C markets*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) 911 Turbo (991) as of 2014 model

	Work instruction for		
Vehicle Ident. No	order no.		
☐ Maintenance			
at 60,000, 120,000, 180,000, 240,000 km/36,000, 72,000 (Labour operation 03 16 00)	0, 108,000, 144,000	miles etc.	
For descriptions of the individual maintenance tasks, see PIW Information: If the mileage for a regular service is not reached, ma			
The term "checking" includes all necessary subsequent work, such not include repairing, replacing and reconditioning parts or assemble to the conditioning parts or assemble to the condition of		ting, correcting and topping up, but does	✓
Electrics			
Windscreen wiper/washer system, headlight cleaning system: che	ck function		
Horn: check function			
Tyres: check tyre pressure (TPM)			
Diagnostic system: read out fault memory; reset maintenance inte	rval		
Inside the vehicle			
Particle filter: replace filter element			
Seat belts: check function and condition			
Door locks: check function			
Luggage compartment			
Check front lid lock and safety hook of the front lid to ensure that t	hey are secure and fur	nction properly	
Replace air intake pre-filter			
Windscreen wiper/washer system: check fluid level; check window	cleaner and antifreez	e, depending on time of year, only use	
windscreen cleaners approved by Porsche			
Outside the vehicle			
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No.	000 043 206 89)**		
Check wiper blades			
All headlights: check adjustment			
Radiators and air intakes: visual inspection for exterior soiling and	blockage		
Brake system: visual inspection of brake pads and brake discs for	wear		
Brake hoses: visual inspection for damage			
Under the vehicle			
Drain engine oil			
Underbody panels: visual inspection for completeness, secure ins	allation and damage		
Tyres: check condition			
Visual inspection for leaks (oils and other fluids)			
Brake lines: visual inspection for damage, routing and corrosion			
Steering gear: visual inspection of the bellows for damage			
Tie rod joints: check the play and dust bellows			
Drive shafts: visual inspection of the boots for leaks and damage			
Axle joints: check the play and visually inspect the dust boots for c	lamage		
Rear-axle steering: check bellows, dust boots and play on joints (S			
Exhaust system: visual inspection for leaks and damage, check er	• • • • • • • • • • • • • • • • • • • •		
Engine compartment	9 9 -		
Air cleaner: replace filter elements			
Change oil filter			
Fill in engine oil			\vdash
Throttle housing: clean inside**			\vdash
Fuel lines and connections: visual inspection			\vdash
Visual inspection for leaks (oils and other fluids)			\vdash
Coolant: check level and antifreeze			\vdash
PDCC: check fluid level			\vdash
			1

^{*} For country allocation, see overview of A, B and C markets

^{**} Applies only for China



Maintenance (C markets*) 911 Carrera / S (991), 911 Carrera 4 / 4S (991) 911 Turbo (991) as of 2014 model

Well-telle Llevid No	Work instruction for	
Vehicle Ident. No	order no.	
Additional maintenance for enouls always		
□ Additional maintenance for spark plugs		
(Labour operation 03 81 00)	20 000 km/40 000 mla an ayam/ 4 yaara	√
Replace spark plugs	every 30,000 km/18,000 mls or every 4 years	-
Replace spark plugs (911 Turbo only)	every 20,000 km/12,000 mls or every 4 years	
☐ Additional maintenance for drive belt		
(Labour operation 03 60 00)		
Check drive belt	at 60,000 km/36,000 mls or every 4 years	
Check drive belt	at 150,000 km/90,000 mls or every 10 years	
Check drive belt	at 240,000 km/144,000 mls or every 16 years	
☐ Additional maintenance for convertible top		
(Labour operation 03 70 00)		
Service and maintain convertible top	every 30,000 km/18,000 mls or every 2 years	
· · ·		
☐ Additional maintenance every 90,000 km/54,000) mls or every 6 years	
(Labour operation 03 83 00)		
Replace PDCC reservoir		
Replace drive belt		
Controlled all-wheel drive: change oil		
☐ Additional maintenance every 120,000 km/72,00	00 mls or every 4 years	
(Labour operation 03 85 00)		
Ancillary unit mounts and chassis: visual inspection of all ru	bber mountings and boots for damage	
	•	
☐ Additional maintenance every 180,000 km/108,0	J00 mls or every 12 years	
(Labour operation 03 88 00)		
Manual transmission: change oil		
All-wheel final drive: change oil		
PDK transmission: change transmission oil		
PDK transmission: change clutch fluid		ļ_
□ Every 2 years		
(Labour operation 03 51 00)		
Change brake fluid (use only original Porsche brake fluid)		
Prepare condition report for long-life guarantee		
Tyre sealing compound: Check use-by date and replace if	necessary	
Signature (mechanic):		
Test debes		
Test drive:		
	brake (also actuation travel), engine, clutch, steering, transmission,	
conditioning and instruments: check function	t switch, sports exhaust system, door mirror fold-in function, heating, air	
Oils, fluids: visual inspection for leaks		-+
Olio, fiuluo. Viouai iriopectioni for leako		
Signature (final about):		—
Signature (final check):	I	I
	Porsche Centre	1
	I Olache Ochine	