

PORSCHE

Maintenance (China) 911 GT2 (997) as of 2009 model

Vehicle Ident. No. _____

Working instruction
for order no.

| |
|--|
| |
|--|

Maintenance

at 40,000, 80,000, 120,000, 160,000 km/24,000, 48,000, 72,000, 96,000 miles etc.
(Labour operation 03 16 00 ..)

For a description of the various models, see Technical Manual

Note: If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term 'checking' includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

| | |
|--|---|
| | ✓ |
| Mix fuel in the tank with additive (Keropur from Porsche; Part No. 000 043 206 89) and check and if necessary affix additional Chinese sticker relating to fuel quality on the tank cap | |
| Diagnostic system: read out fault memory; reset maintenance interval | |
| Change engine oil and oil filter (please observe oil change service plan for the 911 GT2) | |
| Check drive belt | |
| Vehicle underbody and engine compartment: visual inspection for leaks (oils and fluids) and chafing damage (lines and hoses) Underbody panels: visual inspection for completeness, secure installation and damage | |
| Coolant hoses: check condition | |
| Radiators and air inlets: visual inspection for external contamination and blockage | |
| Coolant: check level and antifreeze | |
| Air cleaner: replace filter element | |
| Particle filter: replace filter element | |
| Fuel system: visual inspection for damage, routing and secure fit of line connections | |
| Handbrake: check free play of handbrake lever | |
| Brake system: visual inspection of brake pads and brake discs for wear | |
| Brake hoses and lines: visual inspection for leaks, damage, routing and corrosion | |
| Steering gear: visual inspection of the bellows for damage | |
| Tie rod joints: check the play and dust boots | |
| Axle joints: check the play and visually inspect the dust boots for damage | |
| Check that the threaded connections of the running gear adjustment at the front and rear are secure | |
| Drive shafts: visual inspection of the boots for leaks and damage | |
| Exhaust system: visual inspection for leaks and damage, check engine mount | |
| Control boxes for exhaust flaps: check operation | |
| Tyres: check condition and tyre pressure | |
| Check the door locks, lid locks and safety hooks of the front lid to ensure that they are secure and functioning properly | |
| Seat belts: check operation and condition | |
| Vehicle lighting: check operation | |
| All headlights: check adjustment | |
| Horn: check operation | |
| Windscreen wiper/washer system, headlight cleaning system: check fluid level and nozzle settings, check antifreeze in winter months; check wiper blades | |
| Electrical equipment, warning and indicator lights: check operation | |
| Battery: check functional state and fluid level | |
| Replace spark plugs: see Additional maintenance | |

Continued overleaf

PORSCHE

Maintenance (China) 911 GT2 (997) as of 2009 model

Vehicle Ident. No. _____

Working instruction
for order no.

| |
|--|
| |
|--|

Additional maintenance for spark plugs
(Labour operation 03 81 00 ..)

| | | |
|-----------------------------|---|-------------------------------------|
| Replace spark plugs 911 GT2 | every 20,000 km/12,000 miles or every 2 years | <input checked="" type="checkbox"/> |
|-----------------------------|---|-------------------------------------|

Additional maintenance every 80,000 km/48,000 miles or every 6 years
(Labour operation 03 82 00 ..)

| | | |
|---------------------|--|--|
| Replace drive belt | | |
| Replace fuel filter | | |

Additional maintenance every 160,000 km/96,000 miles or every 12 years
(Labour operation 03 86 00 ..)

| | | |
|---------------------------------|--|--|
| Manual transmission: change oil | | |
|---------------------------------|--|--|

Every 2 years

| | | |
|---|--|--|
| File condition report for long-life guarantee | | |
| Change brake fluid | | |

Every 4 years

| | | |
|----------------------|--|--|
| Replace tyre sealant | | |
|----------------------|--|--|

After 4 years, then every 2 years

| | | |
|---|--|--|
| Check tyre pressure monitoring system battery | | |
|---|--|--|

After 4, 8, 10 years, then every 2 years

| | | |
|--|--|--|
| Ancillary unit mounts and suspension: visual inspection of all rubber mountings and boots for damage | | |
|--|--|--|

Signature (fitter): _____

Test drive:

| | | |
|--|--|--|
| Remote control, front seats, footbrake and handbrake (also actuation travel), engine, clutch, steering, transmission, cruise control, TC switch, PASM switch, Sport switch, heating, air conditioning and instruments: check operation | | |
| Oils, fluids: visual inspection for leaks | | |

Signature (final check): _____