

PORSCHE

Maintenance (C markets*)

911 GT3 (991)

as of 2014 model

Vehicle Ident. No. _____

Work instruction
for order no.

Maintenance

at 40000, 80000, 120000, 160000 km / 24000, 48000, 72000, 96000 miles etc.

(Labour operation: 03 16 00..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Note: If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

✓

| | |
|---|--|
| Electrics | |
| Windscreen wiper/washer system, headlight cleaning system: check function | |
| Horn: check function | |
| Tyres: check tyre pressure (TPM) | |
| Diagnostic system: read out fault memory; reset maintenance interval | |
| Inside the vehicle | |
| Particle filter: replace filter element | |
| Seat belts: check function and condition | |
| Door locks: check function | |
| Luggage compartment | |
| Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly | |
| Replace air intake pre-filter | |
| Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windscreen cleaners approved by Porsche | |
| Outside the vehicle | |
| Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)] | |
| Check wiper blades | |
| All headlights: check adjustment | |
| Radiators and air intakes: visual inspection for external contamination and blockage | |
| Brake system: check brake pads and brake discs for wear | |
| Brake hoses: visual inspection for damage | |
| Check central lock on wheels | |
| Under the vehicle | |
| Drain engine oil | |
| Change oil filter | |
| Underbody panels: visual inspection for completeness, secure installation and damage | |
| Tyres: check condition | |
| Visual inspection for leaks from underneath (oils and other fluids) | |
| Brake lines: visual inspection for damage, routing and corrosion | |
| Steering gear: visual inspection of the bellows for damage | |
| Tie rod joints: check play and dust bellows | |
| Drive shafts: visual inspection of the boots for leaks and damage | |
| Axle joints: check the play and visually inspect the dust boots for damage | |
| Rear-axle steering: check bellows, dust boots and play on joints | |
| Check that threaded connections for chassis adjustment at front and rear are secure | |
| Check vehicle height | |
| Exhaust system: visual inspection for leaks and damage, check engine mount | |
| Control boxes for exhaust flaps: check function | |

PORSCHE

Maintenance (C markets*)

911 GT3 (991)

as of 2014 model

Vehicle Ident. No. _____

Work instruction
for order no.

| |
|--|
| |
|--|

| Engine compartment | |
|---|--|
| Air cleaner: replace filter elements | |
| Replace drive belt | |
| Fill in engine oil | |
| Throttle housing: clean inside (China only) | |
| Fuel lines and connections: visual inspection | |
| Coolant: check level and antifreeze | |

* For country allocation, see overview of A, B and C markets

PORSCHE

Maintenance (C markets*)

911 GT3 (991)

as of 2014 model

Vehicle Ident. No. _____

Work instruction
for order no.

| |
|--|
| |
|--|

- Additional maintenance every 2 years**
(Labour operation: 03 51 00..)

| | |
|---|--|
| Change brake fluid (use only original Porsche brake fluid) | |
| Prepare condition report for long-life guarantee | |
| Tyre sealing compound: check use-by date and replace if necessary | |

- Additional maintenance for spark plugs**
every 20000 km / 12000 miles or every year
(Labour operation: 03 81 00..)

| | |
|---------------------|--|
| Replace spark plugs | |
|---------------------|--|

- Additional maintenance every 80000 km / 48000 mls or every 6 years**
(Labour operation: 03 82 00..)

| | |
|---------------------------------------|--|
| PDK transmission: change clutch fluid | |
|---------------------------------------|--|

- Additional maintenance every 120000 km / 72000 mls or every 4 years**
(Labour operation: 03 85 00..)

| | |
|---|--|
| Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage | |
|---|--|

- Additional maintenance every 160000km / 96000mls or every 12 years**
(Labour operation: 03 86 00..)

| | |
|---|--|
| PDK transmission: change transmission oil | |
|---|--|

Signature (mechanic): _____

Test drive:

| | |
|---|--|
| Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, PDK Sport switch, Lift switch, sports exhaust system, heating, air conditioning and instruments: check function | |
| Oils, fluids: visual inspection for leaks | |

Signature (final check): _____

| |
|----------------|
| Porsche Centre |
|----------------|