	R	5	H	

Maintenance (C markets*) 911 GT3 / GT3 RS (991) as of 2015 model

Vehicle Ident. No.

Work instruction for order no.

□ Maintenance

at 40000, 80000, 120000, 160000 km / 24000, 48000, 72000, 96000 miles etc. (Labour operation: 03 16 00..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual **Note:** If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12..... years. The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

Electrics	+			
	+			
Windscreen wiper/washer system, headlight cleaning system: check function	_			
Horn: check function				
Tyres: check tyre pressure (TPM)				
Diagnostic system: read out fault memory; reset maintenance interval	+			
Inside the vehicle				
Seat belts: check function and condition				
Particle filter: replace filter element				
Door locks: check function				
Luggage compartment				
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly				
Replace air intake pre-filter				
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of				
year, only use windscreen cleaners approved by Porsche				
Outside the vehicle				
Check wiper blades				
All headlights: check adjustment				
Radiators and air intakes: visual inspection for external contamination and blockage				
Brake system: check brake pads and brake discs for wear				
Brake hoses: visual inspection for damage				
Check central lock on wheels				
Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)]				
Under the vehicle				
Underbody panels: visual inspection for completeness, secure installation and damage				
Tyres: check condition				
Visual inspection for leaks from underneath (oils and other fluids)				
Brake lines: visual inspection for damage, routing and corrosion				
Steering gear: visual inspection of the bellows for damage				
Tie rod joints: check play and dust bellows				
Drive shafts: visual inspection of the boots for leaks and damage				
Axle joints: check the play and visually inspect the dust boots for damage				
Rear-axle steering: check bellows, dust boots and play on joints				
Check that threaded connections for chassis adjustment at front and rear are secure				
Check vehicle height				
Exhaust system: visual inspection for leaks and damage, check engine mount				
Control boxes for exhaust flaps: check function				



Maintenance (C markets*) 911 GT3 / GT3 RS (991) as of 2015 model

Vehicle Ident. No.

Work instruction for order no.

Engine compartment

Air cleaner: replace filter elements (GT3 only)

Replace drive belt

Fuel lines and connections: visual inspection

Coolant: check level and antifreeze

Throttle housing: clean inside (China only)

* For country allocation, see overview of A, B and C markets

Maintenance (C markets*) 911 GT3 / GT3 RS (991) as of 2015 model							
Vehicle Ident. No. Work instruction for order no. For order no.							
Additional maintenance every 2 years (Labour operation: 03 51 00)							
Change brake fluid (use only original Porsche brake fluid)							
Prepare condition report for long-life guarantee							
Tyre sealing compound: check use-by date and replace if necessary							
Additional maintenance for spark plugs							
every 20000 km / 12000 mls or every 2 years							
(Labour operation: 03 81 00)							
Replace spark plugs							
Additional maintenance every 80000 km / 48000 mls or every 6 years							
(Labour operation: 03 82 00)							
PDK transmission: change clutch fluid							
Additional maintenance every 120000 km / 80000 mls or every 4 years							
(Labour operation: 03 85 00)							
Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage							
Additional maintenance every 160000km / 96000mls or every 12 years							
(Labour operation: 03 86 00)							
PDK transmission: change transmission oil							
Signature (mechanic):							
Test drive:							
Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, PDK Sport switch, PIT SPEED switch (GT3RS), Lift switch, sports exhaust system, heating, air conditioning and instruments: check function							
Oils, fluids: visual inspection for leaks							
Signature (final check):							

Porsche Centre